


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	0577040	Literature Parts	5	3952499	Timer, Control (60 Hz.)	22	3390646	Screw, (8-18 x 5/16)
	03/1210	Installation Instructions			(Automatic Washer)	23		Panel, Control
	8578179	Use & Care Guide	6	8528154	Bracket, Control		3977194	
	8542754	•	7		End Cap, Console	24	3977195	Biscuit Knob, Timer
	8577335	Cycle Feature Wiring Diagram		692993	(L.H. & R.H.) White	24		(Dryer)
	3954161	Energy Guide		3978584			3957752	
			8		Screw, 8-18 x 3/4	0=	3957753	
2	8577368	Harness, Console	9		Screw, 8–18 x 3/8	25		Knob,
		Wiring (Automatic)	10		Switch, Water Level		2057000	Push-To-Start White
		(Includes Illus.	11		Spring-Clip, Knob		3957800 3957801	Biscuit
2A	2250120	2A, 2B & 2C) Plug, Terminal	12	8054142	Switch, Water Temperature	27	3937601	Knob, Control (2)
ZA	3330130	(2–Way)	14	693151			3957796	
		(Connects With	' '		Lock (2)		3957797	Biscuit
		Main Dryer	15	3400860	Screw, Console	28		Dial, Timer
		Harness)			Lock (2)			(Washer)
2B	696073	Receptacle,	16	3406720			3957841	
		Connector			(60 Hz.) (Dryer)	29	3957842	
		(Connects With			(Timer Motor Not Serviceable)	29		Knob, Timer (Washer)
		Lower Automatic Harness)	18	3977456			3957821	
2C	3948614		'Ŭ	0011400	Push-To-Start		3957822	
20	55 - 551 -1	(Connects With	19	693152	Bumper, Console (5)	31	692983	Lock, Console (2)
		Automatic Timer)	21	694037		32	694419	Buzzer

DRYER FRONT PANEL AND DOOR PARTS




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3406108	Door Switch	7		Door, Front	13	343641	Screw, 10-16 x 1/2
2	697773	Screw, 6-20 x 7/8		348205	White	14	3389441	Catch, Door
4		Panel, Front		3978598	Biscuit	15		Handle, Door
	692619	White	9	8066123	Bearing & Seal		686711	White
	3978587	Biscuit	10		Clip, Felt		3978592	Biscuit
5	3390734	Seal, Door			Pad (2)	19	694091	Screw, 8-18 x 3/8
6	695656	Door, Rear	11	696144	Strike, Panel	20	348023	Hinge & Pin,
			1 12	3390663	Screw 10-16 x 1/2			Door (2)

DRYER CABINET AND MOTOR PARTS

DRYER CABINET AND MOTOR PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	660658	Clamp, Motor Mounting (2)	21	8066051	Pulley, Motor (60 Hz.)	31		Closure, Control Area
2	8538265		22	691366			692781 3978599	White Biscuit
3	3352501	Clip	23	692771	Nut, Idler	32	354975	(-)
4	3351614	Screw, 10-24 x 3/8			Bracket To Base			(Lid Latch
5	696541	Bracket, Motor	24	3399633	, ,			Mounting)
6	3390405	Panel, Rear	25	692400	Nut, Push-In	33	693304	· ,
7	343641	Screw, 10-16 x 1/2	26	692926	,			(Transition Panel
8	3394228	Cover, Terminal			Panel (Black)			To Closure)
		Block	27		Panel, Transition	34	697776	,
10		Panel, Side (L.H.)		692933				(10-32 x 5/8)
	3402293	White		3978591	Biscuit	35	3390631	,
	3978589	Biscuit	28	692641	Top, Dryer	36	8572717	
14		Elbow, Upper	29		Panel, Side (R.H.)			Start (Automatic
15	3394083	Clip, Front		3402287				Washer)
		Panel (2)		3978590		37	357030	
16	98234	Clip, Ground	30	693145	Latch, Lid	38	343641	Screw, Capacitor
17		Elbow, Lower						Mounting
20	8066064	Belt, Drive				41	686770	5 /
			l			44	90296	Clip

DRYER BULKHEAD PARTS




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER BULKHEAD PARTS

IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
			29	8531967	Cover, Lint	39	694415	Strain Relief,
1		Screw, 10-16 x 1/2		000.001	Screen Outlet		000	Power Cord
2	3395396	Clip, Air Duct	30	690997	Tri-Ring (4)	40	3388703	Washer, Support
2	0500407	To Bulkhead	31	3399506	Shaft, Drum	41	279393	Screw Kit
3 4		Air Duct & Cover Terminal			Roller (L.H.)			(For Terminal
5	3398128		32	3397590				Block)
J	3330120	Internal Bias	33	348197		42	279318	,
6	348378	Screen, Back-up	34		Nut, 3/8–16 (2)			& Brass (3)
8	3403140		35		Screw, 10–16 x 3/8	40	007770	(Includes Illus. 41)
Ŭ	0.001.10	Heater Box	36	8299829		43		Screw, 10–32 x 1/2
		205°F (96C)			Dryer Wiring	44 46		Screw, 8–18 x 1/2
9	489463				(Includes Illus.	46 47		Screw, 8–18 X 3/8 Thermal Limiter
10	3398161	Clip, Heater Box	36A	717050	36A, 36B, 36D) Receptacle,	47	03/2/0/	195°F (91C)
		To Bulkhead	30A	111232	Terminal (2–Way)	48	359702	Cap, Screw
11	697269	Heater Box			(Connects With	49		Clip, Strain
13	339956	Seal, Air Duct			Door Switch	43	200000	Relief
		To Bulkhead			Harness)	50	3400935	Clip, Harness
14		Wheel, Blower	36B	697780		51		Drum, Hole Plug
16	8066094	Seal, Fan	002	0000	(Gas Valve)	52		Cover, Manifold
		Scroll	36D	3395683	Receptacle,	53		Support,
17		Fan Scroll			Multi–Terminal			Heater Box
21	3399507	Shaft, Drum			(Connects With	54	3387208	Support,
00	005040	Roller (R.H.)			Dryer Motor)			Corner Gas
22		Drum, Dryer	37	693141	Clip, Wiring	55	697571	Guard, Sock
23	3394508	Ring, Bearing			Harness (3)	56	3402856	Burner
24 25		Baffle, Drum (3) Screw, 11–16 x 3/4	38	694018	Cord, Power			(Refer to page 19
25 26								For Complete
20 27		Seal, Drum Rear Bulkhead						Breakdown)
28		Lint Screen						


DRYER SUPPORT AND WASHER PARTS For Models: LTG5243DQ6, LTG5243DT6

(Designer White) (Biscuit)




llus. No.	Part No.	DESCRIPTION
1	694304	Cover, Channel
2	692647	Support,
3	343641	Dryer (L.H.) Screw, 10–16 x 1/2
3 4	3400000	Screw,
		10-24 x 3/8 (8)
		(Washer Cabinet
5	692646	To Dryer Supports) Support,
J	002040	Dryer (R.H.)
6	3957867	Harness, Lower
		(Automatic)
		(Includes Illus. 6A, 6B & 6C)
6A	696074	
		(12–Way)
		(Connects With Automatic Console
		Harness)
6B	62889	
		(3–Way)
		(Connects With Automatic Lid
		Switch Harness)
6C	62505	Block, Disconnect
		(Connects With
		Automatic Washer Motor)
7	3347812	Clip, Wiring
		Harness (4)
8	8066080	Hose, Pressure
11	90016	Switch Clip, Pressure
	30010	Switch Hose (2)
12	693141	Clip, Harness

WASHER TOP AND LID PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3398848 3398849		6	384693 3978593		9		Strike, Lid Switch Screw, 10–24 x 1/2
2	384475 91770	Bumper, Lid (2) Hinge, Lid (2)	7	21258	Bearing, Lid Hinge (2)	11	8533959	Nut, Ground Screw
4 5		Screw, Lid Hinge Mounting (4) Clip, Spring (2) (Top To Cabinet)	8	3356311	Screw & Washer, Lid Switch Shield (2)	12 13		Switch, Lid Clip, Harness Routing

WASHER CABINET PARTS




WASHER CABINET PARTS For Models: LTG5243DQ6, LTG5243DT6


(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1 2 3	356746 343641 9740848	Clip, Condenser Screw, 10–16 x 1/2 Screw, Mixing Valve Mounting
5	3952163	Valve, Water Mixing
6 7	370451 692699	Clamp, Hose Hose, Water Inlet (Siphon Break To Mixing Valve)
8	696013	Cabinet White
9 10 11 12	3978594 3390046 696710 692400 660975	Biscuit Protector, Edge Hose, Drain Nut, Push–In (2) Plug, Top To Cabinet
13 14 15 16 17 18	8557915 370445 356471 356363 272861 696394	Connector, Hose Clamp, Hose Cap, Siphon Break Siphon Break Clamp, Hose Hose, Water Inlet (Siphon Break To
19 20 22 23 24	367594 358594 3394083 358652 359364	Tub Ring) Foot, Front (2) Foot, Rear (2) Clip, Front Panel Link, Leveling Clip, Leveling
25 26 27	98234 345670 692628	Mechanism (2) Clip, Ground Lock, Top (2) Panel, Front White
31	3978596 3350013	Biscuit Foam (2)


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS



MACHINE BASE PARTS




TUB AND BASKET PARTS




Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	
3	63840	Filter, Agitator
4	3349098	
5	64175	Tub Ring &
		Gasket (Includes
		Illus. 7, 14 & 15)
6 7	21366	Nut, Spanner
7	3359587	Gasket,
		Tub Ring
8	3351985	
9	8066082	Tub
10	389140	Block,
		Basket Drive
11	3949550	Washer
12	3363366	Clamp, Hose
13	8066201	
		To Pump
14	352155	
15	356398	Tube,
		Drain Off
16	357640	Screw & Washer
		(Tub Mounting)
17	383727	Gasket,
		Centerpost

WATER SYSTEM PARTS




GEARCASE PARTS

For Models: LTG5243DQ6, LTG5243DT6



BRAKE AND DRIVE TUBE PARTS

For Models: LTG5243DQ6, LTG5243DT6 (Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	387948	Brake And Drive Tube (Complete)
2 3 4	62658 356427 64027	Ring, Thrust
5	64035	
5 6 7	64232 62703	, , ,
8	3353956	
9	63748	
10	3355360	Sleeve, Brake Spring
11	661516	
12	63022	Sleeve, Cam
13	64194	- ,
14	90368	Cam Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED


285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

PRODUCT ACCESSORY PARTS



Illus. No.	Part No.	DESCRIPTION
1	279823	Side Exhaust Extension Kit (Complete)
2	488729	
3	3395536	Clip

MISCELLANEOUS PARTS




Illus. No.	Part No.	DESCRIPTION
1	3359934	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose (4)
3	370445	Clamp, Hose
4	367594	Foot, Front (2)
5	358594	Foot, Rear (2)
6		Tie, Cable
7	3357331	Clamp, Hose
		(Upper Drain)

3402856 BURNER ASSEMBLY

For Models: LTG5243DQ6, LTG5243DT6 (Designer White) (Biscuit)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3402856	Burner Assembly 60 Hz.	9	694421	Screw, 8–32	22 23	3406051 3388638	Elbow Union Assembly Nipple, Short
2	697408	Base, Burner	10	694538	Bracket, Shunt	24	3391118	Supply Line
3	3401777	Valve, 60 Hz.	11	694422	Spring, Regulator			(Gas)
4		Orifice	12	239822	Pipe, Plug	25	233076	Nut
	234822	Natural Gas	13	694423	Screw	26	3393767	Pipe
	347743	L.P. Gas	15	3392268	Burner			
5	3401849	Harness	16	3387057	Screw, 8-18 X 3/8	Fol	lowing Pa	arts Not Illustrated
6	694539	Coil, 60 Hz.	17	686590	Ignitor			
		(Split)	18	3393909	Screw and Washer		49573	Conversion Kit
7	694540	Coil, 60 Hz.			8–32 x 1			(Type 1, 2 & 3)
8	694424	Leak Limiter	20	697409	Bracket, Sensor			to Type (4) L.P.G.
			21	338906	Sensor, Radiant			31 - ()

OPTIONAL PARTS (NOT INCLUDED)

For Models: LTG5243DQ6, LTG5243DT6 (Designer White) (Biscuit)

Illus. **Part**

DESCRIPTION No. No.

PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit

PAINT, PRESSURIZED SPRAY

(12 oz.)

350938 Primer, Gray 350930 White 4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut)

ACCESSORY PARTS

Plug, Dryer Side Panel 692790 White 3977784 Biscuit

OIL

350572 Oil, Gearcase (16 Oz.)

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)